



# Datejust 31

Oyster, 31 mm, Everose gold and diamonds

This Oyster Perpetual Datejust 31 in 18 ct Everose gold features a chocolate, diamond-set dial and a President bracelet.



CHOCOLATE DIAL

# A watchmaking technique

This dial features a large VI set with 11 diamonds. The sunray finish creates delicate light reflections on many dials in the Oyster Perpetual collection. It is obtained using masterful brushing techniques that create grooves running outwards from the centre of the dial.

Light is diffused consistently along each engraving, creating a characteristic subtle glow that moves depending on the position of the wrist.

Once the sunray finish has been completed, the dial colour is applied using Physical Vapour Deposition or electroplating. A light coat of varnish gives the dial its final look.



DIAMOND-SET BEZEL

## A sparkling symphony

Gem-setters, like sculptors, finely carve the precious metal to hand-shape the seat in which each gemstone will be perfectly lodged. With the art and craft of a jeweller, the stone is placed and meticulously aligned with the others, then firmly secured in its gold or platinum setting.

Besides the intrinsic quality of the stones, several other criteria contribute to the beauty of Rolex gem-setting: the precise alignment of the height of the gems, their orientation and position, the regularity, strength and proportions of the setting

as well as the intricate finishing of the metalwork. A sparkling symphony to enhance the watch and enchant the wearer.



18 CT EVEROSE GOLD

## An exclusive patent

To preserve the beauty of its pink gold watches, Rolex created and patented an exclusive 18 ct pink gold alloy cast in its own foundry: Everose gold.

Introduced in 2005, 18 ct Everose is used on all Rolex Oyster models in pink gold.



THE PRESIDENT BRACELET

### The ultimate refinement

The design, development and production of Rolex bracelets and clasps, as well as the stringent tests they face, involve advanced high technology.

And, as with all the components of the watch, aesthetic controls by the human eye guarantee impeccable beauty. The President bracelet, with its semi-circular three piece links, was created in 1956 for the launch of the Oyster Perpetual Day-Date. It represents the ultimate in refinement and comfort and is always made of carefully selected precious metals.

# More Datejust technical details

Reference 278285RBR

#### **Model Case**

#### **Type**

Oyster, 31 mm, Everose gold and diamonds

#### **Diameter**

31 mm

#### **Material**

Everose gold

#### **Bezel**

Set with diamonds

#### **Oyster Architecture**

Monobloc middle case, screw-down case back and winding crown

#### **Winding Crown**

Screw-down, Twinlock double waterproofness system

#### **Crystal**

Scratch-resistant sapphire, Cyclops lens over the date

#### **Water Resistance**

Waterproof to 100 metres / 330 feet

#### **Movement**

#### **Type**

Perpetual, mechanical, self-winding

#### **Calibre**

2236, Manufacture Rolex

#### **Precision**

-2/+2 sec/day, after casing

#### **Oscillator**

Syloxi hairspring in silicon with patented geometry. High-performance Paraflex shock absorbers

#### Winding

Bidirectional self-winding via Perpetual rotor

#### **Power reserve**

Approximately 55 hours

#### **Functions**

Centre hour, minute and seconds hands. Instantaneous date with rapid setting. Stop-seconds for precise time setting

#### **Bracelet**

#### **Type**

President, semi-circular three-piece links

#### **Bracelet Material**

18 ct Everose gold

#### Clasp

Concealed folding Crownclasp

#### **Dial**

#### **Type**

Chocolate set with diamonds

#### Certification

#### **Type**

Superlative Chronometer (COSC + Rolex certification after casing)

# Explore and discover more on Rolex.com

All intellectual property rights such as trademarks, service marks, trade names, designs and copyrights are reserved.

Nothing contained in this website may be reproduced without written permission. Rolex reserves the right at all times to modify the models featured in the present website.

